

# MDE 185



**“A Manager vers. 4” for PC**

**Installation and User Manual**

3	18-11-2014	Mod F02 new version	<i>D.Bellinzona</i>	<i>A.Battaglia</i>
2	12-05-2010	Mod F02 Operat.	<i>M. Giuliani</i>	<i>A. Affaticati</i>
1	11-02-2009	Mod. Import funct.	<i>M. Giuliani</i>	<i>A. Affaticati</i>
0	21-03-2008	First Issue	<i>G. Riboli</i>	<i>A. Affaticati</i>
<b>Rev.</b>	<b>Date</b>	<b>Description</b>	<b>Prepared</b>	<b>Approved</b>

*BIFFI ITALIA has taken every care in collecting and verifying the documentation contained in this Installation and User Manual.*

*The informations herein contained are reserved property of BIFFI ITALIA.*

# INDEX

<b>1</b>	<b>INTRODUCTION</b>	<b>4</b>
<b>2</b>	<b>INSTALLATION INSTRUCTIONS</b>	<b>4</b>
2.1	To install A Manager PC	4
2.2	To uninstall the Manager PC	5
<b>3</b>	<b>USER MANUAL</b>	<b>6</b>
3.1	General Notes	6
3.2	Start the Program	7
3.3	Setup	7
3.4	Login	9
3.5	Working mode	10
3.6	Connection to actuator	10
3.6.1	Connection to ICON /F01 / EFS 2000v4	11
3.6.2	Connection to F02 (EPI 2)	12
3.6.3	Connection to MCU	13
3.7	Manual discovery of Bluetooth slave devices	13
3.8	Exit from A-Manager	14
<b>4</b>	<b>A-MANAGER FOR ICON/F01/ EFS 2000 V4</b>	<b>15</b>
4.1	User Interface	15
4.2	Actuator environment	17
4.2.1	Actuator Setup	17
4.2.2	Name Plate	18
4.2.3	Valve Data	19
4.2.4	Maintenance	20
4.2.5	Restricted	21
4.2.6	Operation	22
4.2.7	Tools	23
4.3	Options environment	25
4.4	Examples for ICON/F01/EFS 2000 v4	26
4.4.1	To Modify the closing torque limit	26
4.4.2	To Export the actuator data to File	27
4.4.3	To export actuator data to EXCEL file	28
4.4.4	To import the actuator data from file	29
4.4.4.1	To write new data to actuator without changing data of one selected TAB	31
4.4.4.2	To write new data to actuator in TAB by TAB mode	32
4.4.4.3	To copy all data from one logic card to another one	32
4.4.5	To download a new firmware / language to actuator	33
4.4.6	To View Torque / PST / EFS curves	34

4.4.7	To view Alarm Logger	36
4.4.8	To view Data Logger	37
<b>5</b>	<b>A-MANAGER FOR F02 (EPI 2)</b>	<b>38</b>
5.1	User Interface	38
5.2	Actuator environment	40
5.2.1	Actuator Setup	40
5.2.2	Operation	41
5.2.3	Tools	42
5.3	Options environment	44
5.4	Examples for F02 (EPI 2)	45
5.4.1	To modify the opening torque limit	45
5.4.2	To export the actuator data to File	46
5.4.3	To export the actuator data to EXCEL file	47
5.4.4	To import the actuator data from file	48
5.4.5	To set new stroke limits in closure	49
5.4.5.1	Closure by torque	49
5.4.5.2	Closure by position	50
5.5	Distinguish OLD/NEW models for F02-EPI2	51
5.5.1	A MANAGER Interface differences into new F02-EPI2 version	53
5.5.1.1	OPENING/CLOSING SPEED (ACTUATOR SETUP section)	53
5.5.1.2	OPENING/CLOSING TORQUE (ACTUATOR SETUP section)	54
5.5.1.3	TORQUE (OPERATION section)	54
<b>6</b>	<b>A-MANAGER FOR MCU 2000 V4</b>	<b>55</b>
6.1	User Interface	55
6.2	Actuator environment	58
6.2.1	Actuator Setup	58
6.2.2	Name Plate	59
6.2.3	Valve Data	60
6.2.4	Maintenance	61
6.2.5	Restricted	62
6.2.6	Operation	63
6.2.7	Tools	65
6.3	Options environment	67
<b>7</b>	<b>A-MANAGER CONVERSION TOOL</b>	<b>68</b>
7.1	Installation process	68
7.2	Start the Program	69
7.2.1	Conversion of file *.set	69
7.2.2	Conversion of file *.i4k	70



<b>8</b>	<b>USERNAME PROFILES AND PERMISSIONS</b>	<b>72</b>
8.1	Permissions for ICON/F01/EFS 2000v4	72
8.2	Permissions for F02 (EPI 2)	74
8.3	Permissions for MCU 2000v4	75
<b>9</b>	<b>EXCEPTION MESSAGES</b>	<b>77</b>

## 1 Introduction

**MDE 185** is the instruction manual of A-MANAGER version 4.x.x. It includes also instruction manual for “A-Manager Conversion Tool”, needed to convert files \*.set, \*.man, and \*.i4k (saved with A-Manager version less than 4.0.0 or prjICON4K.exe) to files \*.icon, \*.f02, \*.mcu, readable by A-Manager version 4.x.x. For A-MANAGER version less than 4.00 refer to instruction manual MAN 660.

## 2 Installation instructions

### Important:



“A MANAGER” for PC installation software consists of two files:


- AManager\_PC\_4.x.x.msi
- Setup.exe

### 2.1 To install A Manager PC

Before initiating installation procedure of a new version of A-Manager remove any previously installed version of A-Manager version 4.x.x (see instructions in par. 2.2, To Uninstall A-Manager PC). A-Manager versions less than 4.0.0 do not need to be removed.

To start the installation process, double-click on setup.exe file.



A simple wizard will guide you through the installation process:



Click Next.

Agree to End User License Agreement

Select installation folder and then click Next



Click “Next” to begin program installation



When the message “Installation complete” appears click Close.

A link (icon with BIFFI logo named **AManager4**) to the executable file (AManager.exe) will be created on the desktop and a new program folder, named “Biffi”, will be added to Start Menu\Program folder.

Double-click one of the links to the executable file or the executable file itself (located in : \destination\_folder\bin\)) to run the program.

## 2.2 To uninstall the Manager PC






In the taskbar click “Start”. Click “Control Panel” and then double click “Add or remove programs”. Click AManager PC .



Click “Remove” and then “YES”. A-Manager PC will be removed and PC is ready to re-install a new A-Manager according to instructions of par 2.1 , “To Install A-Manager PC”.

### 3 USER MANUAL

#### 3.1 General Notes


<p><b>Warning:</b></p> 	<p>For any information regarding actuator parameters or settings please refer to the relevant Biffi Actuator documentation.</p> <p>Wrong parameter settings may cause actuator malfunctions.</p>
<p><b>Warning:</b></p> 	<p>All parameters changes which were not saved to the internal application database or sent to the actuator will be lost once the application is closed.</p>
<p><b>Warning:</b></p> 	<p>It is assumed that the installation, setting, commissioning, maintenance and repair works are carried out by qualified personnel and checked by responsible Specialists.</p>
<p><b>Warning:</b></p> 	<p>Any repair work other than the operations outlined in this manual will be strictly reserved to qualified BIFFI ITALIA personnel or to personnel directly authorised by the Company itself.</p>
<p><b>Warning:</b></p> 	<p>Whenever the PC will be used in HAZARDOUS AREA as defined by the applicable rules, it is mandatory to check whether the PC nameplates indicate their suitability to an hazardous area, and the appropriate protection degree.</p>

### 3.2 Start the Program

“A Manager” Software for PC starts with the following screen.

Click “Setup” to select the communication medium.


Enter “Username”, “Password”, “Actuator”, “Operator name” and then click “Login” to run the program.



The screenshot shows the 'AMANAGER - Setup' window. It features a BIFFI logo and the text 'AManager'. Below the header, there are four input fields: 'Username' (a dropdown menu with 'User' selected), 'Op. Name' (a text box), 'Password' (a text box), and 'Actuator' (a dropdown menu with 'ICON' selected). At the bottom, there are two buttons: 'Setup' and 'Login'. The version number '4.0.3' is displayed at the bottom center.

### 3.3 Setup

The following screen appears. Select “Channel”, “COM” and “Baud Rate” according to below instructions.



The screenshot shows the 'AMANAGER - Setup' window with the BIFFI logo. It displays three configuration fields: 'Channel' (a dropdown menu with 'RS-232' selected), 'COM' (a spinner box with '1' selected), and 'Baud Rate' (a dropdown menu with '9600' selected). At the bottom, there are two buttons: 'Close' and 'Save'.

**Channel : RS-232**

- channel RS-232 is not available for F02 (EPI 2) actuators. Connection to actuator can be done only by Bluetooth channel
- select Channel RS-232 if the connection between PC and actuator is made by a RS232 cable. In the line COM select the serial port number of PC. In Baud Rate line select the transmission speed (9600 baud or 115200 baud).

**Channel : Bluetooth**

- select Bluetooth if a wireless Bluetooth connection between PC and actuator is available. The baud rate is automatically set at **115200** bit/sec. The new A-manager version 4 is provided of “**device discovery function**” that allows to find the Bluetooth slave devices to be linked to PC. It means that pairing operation needed with A-manager version less than 4 are no longer necessary. The following options are available:
  - If the PC has an “integral Bluetooth device” and Service Pack 2, the included Microsoft Generic Bluetooth Radio Driver is used. The COM number is automatically set.
  - If it is used an “external USB Bluetooth adapter” the following two options are available
    - The USB Bluetooth adapter can works with standard Microsoft Generic Bluetooth Radio and PC has Service Pack 2, it is not necessary to install any Bluetooth WIDCOMM driver. The Bluetooth adapter can be used without having before installed its own WIDCOMM driver, provided together the USB Bluetooth adapter. If a WIDCOMM driver is already installed , it is suggested to uninstall it and then reboot the PC. The COM number is automatically set.
    - If USB Bluetooth adapter cannot be used with Microsoft Generic Bluetooth Radio but it is necessary to install its own WIDCOMM driver , it needs to follow the relevant instructions to activate the driver. In the above case it needs to set the COM number according to the configuration of WIDCOMM driver.

To make easier the Bluetooth use, it is suggested to select USB Bluetooth adapter that can use Microsoft Generic Bluetooth Radio. This is normally indicated in the instruction manual of USB Bluetooth adapter. An alternative way to understand if the USB Bluetooth adapter can work with Microsoft Generic Bluetooth Radio is to insert the adapter in the USB port of PC and then to see if in the right corner of the notification area (low bar of PC screen) appears the blue/white Bluetooth icon . If yes, the adapter is recognized and can work without installing the WIDCOMM driver. If not, remove immediately the adapter from USB port and proceed to install the WIDCOMM driver provided with the adapter

Note: right click on the icon “Device manager” and then click “properties”, to view PC resources. Click Hardware, Device manager, Bluetooth Radios to see the active Bluetooth driver.

Note: after the disconnection of A-manager from an actuator, it needs to wait at least 30 sec before re-connecting the same actuator.



**Note : IrDA operation**

- This mode is available only if the PC is provided of external RS 232 to IrDA converter/probe ( for instance ACTiSYS infrared wireless adapter ACT-IR220L+ ). No IrDA driver is requested since the A-Manager works in RS-232 mode. The maximum baud rate is 9600 baud.

Click “Close” to exit from Setup without any change


or alternatively

Click “Save” to enter the new setup . Click “Close”, click Yes .



Exit from A-Manger by the **red “X”** on the right upper corner of the “A-Manager- Setup” screen and then double click the A-Manager icon on the desktop to restart with the new settings.

### 3.4 Login



- Enter “Username and Password” :
  - Four username are available: Observer, User, Service e Manufacturer (Service and Manufacturer username are reserved for Biffi authorized personnel use only).

**Observer** username allows only to view data, export data to file, import data from file, but change data is not allowed. Default password supplied by BIFFI is “00000000”.

**User** username allows viewing data, exporting to file and importing from file as Observer can do, in addition the User profile also to modify data in the Actuator Setup, Valve data, Maintenance, and modify “User and Observer” passwords.

Default password supplied by BIFFI is “99999999”.

End user can modify the Observer and User password only by entering as User. After entering the new password the old one ceases to be valid. Therefore it is mandatory “NOT FORGET THE PASSWORD” after the default one has been modified.

**Service** username has the User permissions and in addition can modify “Restricted” and “Name Plate” data.

**Manufacturer** username can modify any data.

Details of permissions relevant to usernames are in the par. 8 , “Username profiles and Permissions”

- Enter “Actuator type” :
  - Three Actuator types are available : ICON/F01/EFS, F02/EPI 2, MCU
- Enter “Operator name” :
  - The field is optional. Icon 2000v4 and MCU 2000v4 memorize the last 8 operator name in a register with data, time and code of the PC. The data can be read by the Maintenance features of A-Manager.
- Click “Login”

### 3.5 Working mode



A-Manager can work in “**disconnected**” or “**connected**” mode

In “**disconnected**” mode the actuator is not connected. A-Manager can work only with files previously exported.

In “**connected**” mode the actuator is connected to PC and data of actuator can be viewed and changed according to username.

To work in “disconnected” mode the following options are available:


1. Start of A-Manager program
  - In Setup , select Channel RS232, select COM not existing in the PC (for instance 99) or select the available COM for RS-232 but do not connect the cable to actuator, and then click Save and Close, then click Login
2. A-Manager already working in “connected” mode
  - In Actuator environment, section Tools, TAB Utility, click Disconnect from actuator



### 3.6 Connection to actuator


By clicking “Login” the A-Manager interrogates the actuator and asks actuator serial number. Two options are available:

- Channel RS-232 : if actuator responds A-Manager runs in “connected” mode and the 3 LED’s of ICON /F01 /EFS/ MCU 2000 actuator flashes few seconds. F02 has no LED’s and no visual indication on the actuator can be done. Indication of connection status is available in the A-Manager user interface
- If actuator does not respond, the A-Manager runs in “disconnected” mode.




- Channel Bluetooth :
  - Device discovery function searches slave devices available and shows icons (ICON 2000, or F02, or MCU2000) and serial numbers (or valve tag), according to actuator configuration
  - Click the actuator to be connected
  - Click “connect”.
  - When connection is established the A-Manager runs in “connected” mode and the three LED’s of ICON / MCU 2000 actuator flashes few seconds. F02 has no LED’s and no visual indication on the actuator can be done. Indication of connection status is available in the A-Manager user interface.
  - If actuator does not respond, the A-Manager runs in “disconnected” mode.
  - after the disconnection of A-manager from an actuator, it needs to wait at least 30 sec before re-connecting the same actuator.

### 3.6.1 Connection to ICON /F01 / EFS 2000v4




When the list of available ICON/F01/EFs’s appears select the ICON/F01/EFs and then click Connect







### 3.6.2 Connection to F02 (EPI 2)



When the list of available F02's appears select the F02 and then click Connect



### 3.6.3 Connection to MCU




When the list of available MCU's appears select the MCU and then click Connect




## 3.7 Manual discovery of Bluetooth slave devices

If the integrated Bluetooth Device Discovery function does not find any Bluetooth device, the following procedure can be useful to check if really no Bluetooth device is available for connection to PC. The procedure can be used only if Microsoft Bluetooth radio is used. Exit from A-Manager.

Double click the blue/white Bluetooth icon in the right corner of notification area (low bar in the PC screen). Select Device and click Add. Click “My device is set up and ready to be found” and then click Next.





The list of available devices appears in the PC screen. Click finish to exit.



### 3.8 Exit from A-Manager

Click the **red X** in high right corner and than click YES to exit from program.



## 4 A-Manager for ICON/F01/ EFS 2000 v4

### 4.1 User Interface

The user interface is organized in **environments** and **sections**. Environments are grouped in the horizontal navigation bar on the top of the screen. Each environment contains sections that are listed in the vertical navigation bar on the left. At present two environments are available : Actuator and Options. The following sections are available in each environment:

Environment	Actuator	Environment	Options
S	Actuator Setup	S	Modify Config
E	Name Plate	E	Password
C	Valve data	C	Object List
T	Maintenance	T	
I	Restricted	I	
O	Operations	O	
N	Tools	N	

Actuator Setup: it contains actuator configuration settings

Name Plate: it contains actuator name plate data

Valve Data: it contains data about the valve onto which the actuator is mounted

Maintenance: it contains maintenance and diagnostics information;

Restricted: it contains actuator advanced settings.

Operations: it is used to remotely send commands to actuator and to read status and alarm information;

Tools: it is used to read and write Card Reports. This section also permits to import and export configurations from and to files, reading and updating actuator firmware and to send various utility commands to actuator.

Modify config: it is used to change the A-Manager settings. The following data can be modified:

- Communication data: Channel, COM n°, Speed
- Language: Italian or English


Password: it allows to change “observer” and “user” password

Object list. It allows to see the object list number and the description of the object function

If username is not enabled to access to a particular a section or environment, the relative button will be disabled.

Sections are organized in **TAB's**. Each TAB contains a subset of information that can be read from and written to the actuator. The data of TAB's are grouped according to organization in the actuator local menu.

Once Environment and Section are selected, click TAB of data to be viewed.



## 4.2 Actuator environment

The Actuator Environment contains information about configuration settings and actuator management. Click Actuator to select the environment.


Click the Section to be viewed. If the A-Manger works in “**connected**” mode, all data of selected section are read from actuator. Click the TAB to view the data on the PC screen. Use button **Refresh** to read again all data of **selected TAB**. Use button **Modify** to activate the “**modify data**” option. Modify the data in the selected TAB and then click **Send** to send all data of selected TAB to actuator or click **Undo** if data should not be changed. Only data of the selected TAB will be sent to actuator. Option **Modify** and **Send** are enabled according to **username profile and permissions**. In Observer username the options **Modify** and **Send** are disabled. In “**disconnected**” mode **Modify** and **Send** can be used to change values of parameter of previously imported file. The modified data can only be saved by the export file/excel functions.

### 4.2.1 Actuator Setup

“Actuator Setup” contains the actuator settings and it allows to view and modify the configuration of actuator according to permission of username.

Data are grouped in TAB (Fail Safe & Interlock, 2-Speed Timer, Miscellaneous , etc), according to the same organization in the actuator local menu. Use the ICON/F01/EFS 2000 v4 instruction manuals to configure the actuators parameters. The following example allows to view or change ESD parameters :

- Click “Actuator Setup”, click “ESD Setup”




## 4.2.2 Name Plate

“Name Plate” contains the actuator name plate and it is possible to view and modify the actuator data according to permission of username. Data are grouped in TAB (Actuator data, Actuator Speed, Power Supply , etc), according to the same organization in the actuator local menu. Use the ICON/F01/EFS 2000 v4 instruction manuals as reference to see name plate parameters description.

The following example allows to view or change the TAB “Actuator Data” :

- Click “Name Plate”, click “Actuator Data”





### 4.2.3 Valve Data

“Valve data” contains the data relevant to the valve and allows to view and modify the above data according to permission of username. Data are grouped in one only TAB (Tag, Serial Number, etc), according to the same organization in the actuator local menu. Use the ICON/F01/EFS 2000 v4 instruction manuals to see valve parameters description.

Click “Valve Data” on the Main Menu. To view the valve data values

AMANAGER - Valve Data

BIFFI

Actuator Management | **Actuator** | Statistics | Options

Actuator Setup | Name Plate | **Valve Data** | Maintenance | Restricted | Operations | Tools

Tag: #5000

Serial Number: q234f

Valve Manufacturer: Vanessa

Break to open torque: 80

Max stem thrust: 100

Valve coupling type: ISO

Ver. 4.0.2 ICON

Refresh | Modify | Send

Username | Manufacturer | (Logout) | Actuator S/N: 031234E02003 | Working Mode: Connected at 115200 bps (RS232)



## 4.2.4 Maintenance

“Maintenance” contains the data relevant to the actuator maintenance and allows to view and modify the above data according to permission of username. Data are grouped in TAB (Data Logger, Alarm Log, Torque Curve, etc), according to the same organization in the actuator local menu. Use the ICON/F01/EFS 2000 v4 instruction manuals to see data description. The following example allows to view or change the “Data Logger” :

- Click “Maintenance” and then “Data Logger”

The screenshot displays the 'AMANAGER - Maintenance' software window. The interface includes a top navigation bar with 'Actuator Management', 'Actuator' (selected), 'Statistics', and 'Options'. A left sidebar contains 'Actuator Setup', 'Name Plate', 'Valve Data', 'Maintenance' (selected), 'Restricted', 'Operations', and 'Tools'. The main area shows the 'Data Logger' tab selected, displaying a table of events. Below the table is a 'Configuration' section with dropdowns for 'Logger Mode' (set to 'Event'), 'Memory Mode' (set to 'Continuous'), and a 'Start Date And Time' field (set to '22/01/2008 8:00'). A 'Sample interval' field is set to '1 sec'. At the bottom, there are 'Refresh', 'Modify', and 'Send' buttons. The status bar at the very bottom shows 'Username', 'Manufacturer', '(Logout)', 'Actuator S/N' (031234E02003), 'Working Mode', and 'Connected at 115200 bps (RS232)'.

Date	Time	Direction	Source
14/03/2008	09.58.08	Opening	Local
10/03/2008	11.25.13	Closing	Local
10/03/2008	10.05.58	Closing	Local
10/03/2008	10.04.18	---	Set stroke limit
10/03/2008	10.04.11	---	Set stroke limit
10/03/2008	10.04.00	---	Configuration via local pushbuttons
10/03/2008	10.02.46	Closing	Local
10/03/2008	10.01.38	---	Set stroke limit
10/03/2008	10.01.33	---	Set stroke limit
10/03/2008	10.01.21	---	Configuration via local pushbuttons
10/03/2008	09.59.00	Closing	Local
	00.00.00	---	No cmd
	00.00.00	---	No cmd
	00.00.00	---	No cmd
	00.00.00	---	No cmd
	00.00.00	---	No cmd

## 4.2.5 Restricted

“Restricted” contains advanced actuator settings. It is possible to view data, but to modify them is allowed only with Service or Manufacturer username. Data are grouped in TAB (One, Two, etc), according to the same organization in the actuator local menu. The following example allows to view or change the TAB “One” :

- Click “Restricted”, click “One”

The screenshot displays the 'AMANAGER - Restricted' software window. The interface includes a top navigation bar with tabs for 'Actuator Management', 'Actuator' (selected), 'Statistics', and 'Options'. A left sidebar contains a menu with 'Actuator Setup', 'Name Plate', 'Valve Data', 'Maintenance', 'Restricted' (selected), 'Operations', and 'Tools'. The main area shows settings for 'One' (selected tab), with fields for 'Reversal Delay' (1), 'Direction Test' (4), 'Voltage Span' (400), 'Torque Stop Zone' (5 %), and 'Speed-By-Pass' (4 sec). Below these are three sections: 'Current Sensor' with values for I=2A (299), I=3.5A (269), I=7A (278), I=15A (316), and I=30A (349); '4-20 mA Config' with values for I=4mA (727), I=20mA (3607), 0=4mA (756), and 0=20mA (3852); and 'Additional Variables' with 'Mask' and 'View' buttons. A 'Back Light' section has 'Auto' and 'On' buttons. At the bottom, there are 'Refresh', 'Modify', and 'Send' buttons. The status bar at the very bottom shows 'Username', 'Manufacturer', '(Logout)', 'Actuator S/N' (031234E02003), 'Working Mode', and 'Connected at 115200 bps (RS232)'.

## 4.2.6 Operation

“Operation” is active only if A-Manager works in “connected” mode and can be used to send commands to actuator and read status and alarm information.

Confirmation is required to enter in this section. To send commands to actuator is available only according to permission of username, if the selector is in LOCAL and if the appropriate actuator setting was done. On the PC screen are present the same information available in the actuator local displays and also the value of the main important variables (torque, speed, voltage, etc.)

The button Output Contacts allows to see the status of output relays, Monitor relay and Auxiliary relays Asi. The button “Alarm/Warning” allows to see the list of alarms and warnings. The line of present Alarms and Warnings are **red**. The button Bus Information allows to see various data relevant to Bus Interface (if it is present). The button Other Info allows to see various data relevant internal counters, A to D converter, etc. The button Reset Alarm/ Warning allows to send a “reset Alarm and Warning” command to actuator.



AMANAGER - Alarms and warnings					
Alarms		Status		Status	
Configuration	Off	Position Sensor	Off	HW1: Local Push-button and Selector	Off
Thermostat	Off	Speed Sensor	Off	Request Signal	Off
Internal Temperature	Off	Main Supply	Off	Direction Test	Off
Alkaline Battery	Off	Lost Phase	Off	HW2: Varing Configuration A-20mA	Off
Hi-Torque CL	Off	K1 Contactor	Off	HW3: 4-20mA not Responding	Off
Hi-Torque OP	Off	K2 Contactor	Off	HW4: Terminal Board Configuration	Off
Jammed in CL	Off	Mid Travel CL	Off	HW5: No Comm. Terminal Board	Off
Jammed in OP	Off	Mid Travel OP	Off	HW6: Varing Configuration from PCL	Off
Warnings		Status		Status	
Hi-Torque OP	Off	Motor Current	Off	OV-TR	Off
Hi-Torque CL	Off	Varing Stroke Limits	Off		
Internal Temperature	Off	Bus Fail	Off		
Main Supply	Off	PST	Off		
Max Contactor Cycles	Off	T-PST	Off		
Maintenance Request	Off	T-RET	Off		

Alarm / warning list

## 4.2.7 Tools

“Tools” is used to read and write Card Reports. This section also permits to import and export configurations from and to the files, reading and updating actuator firmware and to send various utility commands to actuator. Data are grouped in TAB , Card report, Import/Export, Firmware/Language, Utility, etc). Availability of the various write operations is according to username permission.

The TAB “Card report” allows to see information relevant to electronic cards present in the actuator.

The TAB “Import/Export” allows the following :

**Export file:** in connected mode it allows to read from actuator and save the present set of actuator data in a file. Files are exported with extension **\*.icon**. In disconnected mode the data in the A-Manager application memory are saved.

**Export EXCEL:** in connected mode it allows to read from actuator and save the complete (or per section) set of actuator data in an EXCEL file. In disconnected mode the data in the A-Manager application memory are exported.

**Import file:** read the complete (or per section) set of actuator data , previously saved, and then send them or not to actuator. Files previously exported with A-Manager version less than 4.00 (**\*.set , \*.man, \*.i4k**) need the conversion in files compatible with the version 4.0.0 . See par. 7, “A-Manager Conversion tool”

Few data can be written to actuator only in TAB by TAB mode (see par. 4.4.4.2 To write new data to actuator in TAB by TAB mode), and most of maintenance data cannot be written to actuator. See the list of the above data in par. 8.1 “Username profiles and permissions”, Table 1 and Table 2


**Import file \*.pic:** import stroke limits data from a file \*.pic

The TAB “Firmware/ Language” allows to download a new firmware and language file to actuator.

The TAB “Utility” allows the following commands :

- Connect /Disconnect to/from actuator (connected or not connected working mode). In Bluetooth mode, after the disconnection of A-manager from an actuator, it needs to wait at least 30 sec before re-connecting the same actuator.
- Change Baud Rate , see also par. 3.3 Setup
- Wink: in connected mode the command causes the 3 LED’s of actuator to blink
- Set Icon Selector: in connected mode the command allows to virtually change the position of actuator local selector from Local, Off, and Clear. Press Local to move the virtual selector to Local, press Off to move the virtual selector to Off . The control will be restored to real actuator local selector by sending Clear or by closing the communication channel between actuator and PC or by re-powering the actuator.
- Change Bluetooth module name: it allows to change the actuator name ( with Bluetooth channel) from actuator serial number to valve tag.

Below is the screen of the TAB “Utility”.



#### Change Bluetooth module name


The procedure is the following:

- Click Modify, select Serial Number or Valve Tag and then click Send. If Bluetooth uses the Microsoft driver to update the name it need to exit from A-Manager, reboot the PC or remove and then re-insert the Bluetooth adapter, re-power the actuator and than run again the A-manager. Alternatively use the manual discovery of Bluetooth device
- If a WIDCOM driver is used the procedure to update depends on the driver type. Refer to instruction manual of driver to update the Bluetooth name.



## 4.3 Options environment

The Options environment allows the user to modify the application configuration parameters and passwords management. Three sections are available: Modify Config., Password, Object list





Modify config: it is used to change the A-Manager settings. The following data can be modified:

- Communication data: RS-232, Bluetooth™
- COM Port number: the number of the COM port to open
- Connection speed: 9.600bps or 115.200bps
- Language: Italian or English

Click Save configuration and then EXIT from A-Manager and run the program again.

Password: it allows to change “observer” and “user” passwords. Press “Confirm” to save changes. Changes are applied with no need to restart the application.



Object list. It allows to see the object list number and the description of the object function. Click Export Object list to export in an Excel file. Select folder and name and then click save



## 4.4 Examples for ICON/F01/EFS 2000 v4



### 4.4.1 To Modify the closing torque limit

With A-Manager working in connected mode, click Actuator environment, and Actuator Setup section.. The A-Manager reads the actuator setup parameters from actuator to A-Manager application program memory.



Reading data from actuator is done by object. Click TAB “Stroke limits and Torque setup”, then click “Modify”. The Modify operation is not allowed with username Observer, according to permission profile.


Enter the new closing torque value (85%) and then click Send. A dialog file advice that the new value will not be written in the actuator memory if the local selector is in Local or Remote. Click Yes. “Send” command writes to actuator all data of selected TAB



The new value will be sent to actuator and then Modify button disabled. New modify session is available by clicking again “Modify”. Click “Refresh” to check the change has done. Refresh command reads only data of selected TAB.


## 4.4.2 To Export the actuator data to File

In the Actuator environment, Tools section, Import/Export tab, press “Export file”. The following save file dialog will appear.



Select destination folder and name of file and press Save. A files with extension \*.icon will be created. The proposed name is a string of characters that includes actuator serial number, date and time.

Press YES to read the complete set of data from actuator, Press No to save the data present in the current application memory. It is important to understand the difference: data currently in the application memory could or couldn't be the same data of the actuator (especially maintenance data can change very often). So to be sure to export hot actuator data, press “Yes” when asked to read data from actuator.



A message will inform when the export process is complete.

Now the configuration is saved in the specified files. Later it is possible to import this configuration by pressing the “Import file” button.


Export data is made by object number. If some data is not correct or out of limits or communication is lost an error message will appears with the Abort, Re-tray, Ignore options. The Object list in the Options environment can help in discovering the incorrect data .





### 4.4.3 To export actuator data to EXCEL file

The function allows saving in an Excel file the complete or “per section” actuator data.

In the Actuator environment, Tools section, Import/Export tab, press “Export Excel”. The following file dialog appears:




Select the sections to be saved , then move to Torque curves and select curves to be saved. Repeat the procedure with PST curves and EFS curves in case of EFS 2000v4. Press Confirm. The following file dialog appears.



Select destination folder and name of file and press Save. A files with extension \*.xls will be created. The proposed name is a string of characters that includes actuator serial number, date and time.


Press YES to read the complete set of data from actuator, Press No to save the data present in the current application memory. It is important to understand the difference: data currently in the application memory could or couldn't be the same data of the actuator (especially maintenance data can change very often). So to be sure to export hot actuator data, press “Yes” when asked to read data from actuator.

When conversion is finished the new file will be open. Export data is made by object number. If some data is not correct or out of limits an error message will appear with the Abort, Re-tray, Ignore options. The Object list in the Options environment can help in finding the description of incorrect data .



#### 4.4.4 To import the actuator data from file

In the Actuator environment, Tools section, Import/Export tab, press “Import file”. Only files with \*.icon extension can be imported. See par. 7, A-Manager Conversion Tool, to import file with different extension. A-Manager can work either in “connected” mode or in “not connected” mode. In “connected” mode the imported data can be sent or modified and then sent to actuator. In “not connected” mode the imported data can be modified and then exported in a new file.




Select the file to be imported and then click Open. Now the actuator data are in application memory of A-Manager. The above dialog file appears.

Press **Cancel** if data should not be transferred to actuator or if working mode is “disconnected”


Select the “Section” of data to send to actuator and then press **OK**. Only “Section” selection is available, sending data of selected TAB is described in the below examples. Selected “Sections” will be sent to actuator **only if enabled by the username profile** and will be memorized in the actuator memory only if the actuator local selector is in OFF . Select “Name Plate” and “Overwrite serial number on actuator” to change all Name Plate data included “actuator serial number”. Place the actuator local selector in OFF before pressing OK or alternatively change virtually the actuator

selector position by the command Change Icon Selector available in Actuator environment, Tools, Utility, according to instructions in par. 4.2.7, Tool. Few data cannot be written to actuator or can be written only in TAB by TAB mode (see par. 8.1, Table 1 and 2).




Import data is made by object number. If some data is not correct or out of limits an error message will appear. With the Abort, Re-tray, Ignore options. The Object list in the Options environment can help in finding the description of incorrect data.

A report is generated if some object is not supported or out of limits.



In the above report, the configuration data can be sent to actuator since objects are not supported by actuator




In the above case a lot of objects are out of limits. The suggested procedure is the following:


- Click Cancel
- Change to “**disconnected**” working mode
- By the Object list and using the functions Modify and Send enter the correct values
- Export the correct data in a new \*.icon file
- Change to “**connected**” working mode
- Import the new corrected \*.icon file and then download to actuator

#### 4.4.4.1 To write new data to actuator without changing data of one selected TAB

Export the present actuator configuration in a file “oldname.icon” by the A-Manager Export to file function  
Import the new configuration file \*.icon by the A-Manager import function. Select Sections and then click OK to send data to actuator. In the below example, sections “Name Plate” and “Valve Data” will not be written to actuator even if allowed by the username profile and permissions. Click OK to send data to actuator



Now import the old configuration previously exported and click Cancel



The old configuration is now present only in the A-Manager application memory. Select the TAB containing the old data to send to actuator (e.g. Actuator environment, Actuator setup section, ESD setup)

Click Modify


Click Send. Only data of selected TAB (ESD setup) will be sent to actuator

Exit and then start again the A-Manager

The above examples allows to write a new configuration file to actuator without changing the TAB ESD setup and sections Valve data and Name Plate

#### 4.4.4.2 To write new data to actuator in TAB by TAB mode

Import the new configuration file \*.icon by the A-Manager import function  
Click Cancel to maintain data in the A-Manager application memory



Write the new data to actuator by the selection of each TAB and then using the command Modify and Send for each TAB.

#### 4.4.4.3 To copy all data from one logic card to another one


The following procedure works only with username Service or Manufacturer. With username Service only the “card report” TAB will not written to actuator.

Place the actuator in fully open or closed position

Export the present actuator configuration in a file \*.icon by the A-Manager Export to file function

Exit from A-manager. Remove the logic card from actuator and install a new one. Start again A-Manager .

Import the previously exported file.



Select all sections and click OK to write data to actuator.

Now it needs to write to actuator the data writable only in TAB by TAB mode (see par. 4.4.4.2 and par 8.1 Table 1 and 2 “Username profiles and permissions”).

Now the new logic card has the same data of the old one, also stroke limits are the same.

Use “Restore” 0% or 100% command to set the present actuator position (fully open or closed).





The above procedure can be performed only with username “Service” or “Manufacturer”

### 4.4.5 To download a new firmware / language to actuator

The function can be used only in “connected” mode and allows to download a new firmware and language to actuator. The files to write in the actuator memory should have \*.bin extension.

- **New Firmware download**

In Actuator environment , click section Tool. Click Tab “Firmware/language”. In Kernel program click “Write To Actuator”. Select folder and “Kernel” file, then click Open. File will be downloaded to actuator.



Repeat the procedure to write to actuator flash memory the files “Erase” and “Firmware”. Click Check Firmware to verify the data are correct. Click Transfer to initiate transferring the new firmware from actuator flash memory to the actuator program memory”. When the operation ends it needs to re-power the actuator. Also it need to close the A-Manager program and restart it again.

- **New Language download**

Use the same procedure to download a new language.


Click section Tool. Click “Language”. Select folder and language file. File will be downloaded to actuator.

Downloading firmware and language can require few minutes.





## 4.4.6 To View Torque / PST / EFS curves

In “connected” mode the function allows to view the torque curve memorized in the actuator memory. In “not connected” mode the function allows to view the torque curves previously saved in a file by means of the “Export file” function. So in “not connected” mode it needs to use the “Import file” option before viewing the torque curves. In Actuator environment and Maintenance section click TAB “Torque curves”. Select curves to view.



Click Details to view details of the selected curves. Select Details also to set the “reference curves”, (signature). Click Full Screen View to utilize the full screen. Right click of mouse to print and save as images the curves





Use the same procedure to view PST and EFS curves in case of EFS actuators



## 4.4.7 To view Alarm Logger

In “connected” mode the function allows to view the alarm log memorized in the actuator memory. In “not connected” mode the function allows to view the alarm logger previously saved in a file by means of the “Export file” function. So in “not connected” mode it needs to use the “Import file ” option before viewing the logger.

In Actuator environment and Maintenance section click TAB “Alarm log”.

The screenshot displays the AMANAGER - Maintenance software interface. The top menu bar includes 'Actuator Management', 'Actuator', 'Statistics', and 'Options'. The left sidebar contains 'Actuator Setup', 'Name Plate', 'Valve Data', 'Maintenance' (highlighted), 'Restricted', 'Operations', and 'Tools'. The main area shows the 'Alarms Log' and 'Warnings Log' tabs. The 'Alarms Log' table lists events such as 'Jammed Valve in Opening' and 'Hi Torque in Opening'. The 'Warnings Log' table lists events such as 'Hi Torque in Opening' and 'Wrong Stroke Limits'. The bottom status bar shows 'Ver. 4.0.2', 'ICON', 'Refresh', 'Modify', 'Send', 'Username', 'Manufacturer', '(Logout)', 'Actuator S/N', '042456E01001Demo-Icon030', 'Working Mode', and 'Connected at 115200 bps (Bluetooth)'.

Date	Time	Description
06/03/2008	14.43.56	Jammed Valve in Opening
04/03/2008	15.48.58	Hi Torque in Opening
04/03/2008	15.47.38	Hi Torque in Opening
04/03/2008	15.47.25	Hi Torque in Closing
04/03/2008	15.47.22	Hi Torque in Opening
27/02/2008	15.15.31	Jammed Valve in Opening
27/02/2008	11.04.24	Hi Torque in Opening
21/02/2008	16.36.36	Mid Travel Alarm in Opening
19/02/2008	15.47.57	Request Signal
19/02/2008	15.43.25	Request Signal

Date	Time	Description
04/03/2008	15.48.58	Hi Torque in Opening
04/03/2008	15.47.38	Hi Torque in Opening
04/03/2008	15.47.25	Hi Torque in Closing
04/03/2008	15.47.22	Hi Torque in Opening
27/02/2008	14.09.27	Wrong Stroke Limits
27/02/2008	14.06.26	Wrong Stroke Limits
27/02/2008	11.04.24	Hi Torque in Opening
26/02/2008	10.05.55	Wrong Stroke Limits
03/02/2008	14.09.27	Mid Travel Alarm in Opening


See ICON/F01/EFS instruction manual for alarm and warning description

## 4.4.8 To view Data Logger

In “connected” mode the function allows to view the data logger memorized in the actuator memory. In “not connected” mode the function allows to view the data logger previously saved in a file by means of the “Export file” function. So in “not connected” mode it needs to use the “Import file” option before viewing the data.

In Actuator environment and Maintenance section click TAB “Data Logger”.

The following figure shows the data logger in “Event” mode



The following figure shows the data logger in “T-recorder” mode



T-logger stops recording in case of torque alarm. The last 256 samples remain in the actuator memory until a new start of logger (by Modify and Send)

See ICON/F01/EFS instruction manual for data logger description

## 5 A-Manager for F02 (EPI 2)

### 5.1 User Interface

The user interface is organized in environments and sections. Environments are grouped in the horizontal navigation bar on the top of the screen. Each environment contains sections that are listed in the vertical navigation bar on the left. At present two environments are available : Actuator and Options. The following sections are available in each environment:

#### Environment

	Actuator
S	Actuator Setup
E	Operations
C	Tools
T	
I	
O	
N	

#### Environment

	Options
S	Modify Config
E	Password
C	Object List
T	
I	
O	
N	

Actuator Setup: contains actuator configuration settings

Operations: it is used to remotely send commands to actuator and to read status and alarm information;

Tools: This section permits to import and export configurations from and to files and to send various utility commands to actuator.

Modify config: only language can be changed since the only communication channel available in F02 actuator is Bluetooth



Password: it allows to change “observer” and “user” password

Object list. it allows to see the object list number and the description of the object function

If username is not enabled to access to a particular a section or environment, the relative button will be disabled.

Sections are organized in TAB's. Each TAB contains a subset of information that can be read from and written to the actuator.

Once Environment and Section are selected, click TAB of data to be viewed.



## 5.2 Actuator environment

The Actuator Environment contains information about configuration settings and actuator management.

Click Actuator to select the environment.

Click the Section to view. If the A-Manger works in “**connected**” mode the data of the section are read from actuator. Click the TAB to view the data on the PC screen. Use button **Refresh** to read again all data of selected TAB. Use button **Modify** to activate the “**modify data**” option. Modify the data in the selected TAB and then click **Send** to send all data of **selected TAB** to actuator or click **Undo** if data should not be changed. Only data of the selected Tab will be sent to actuator. In Observer username the option **Modify** is disabled. In “**disconnected**” mode, **Modify** and **Send** can be used to change values of parameter of previously imported file. The modified data can only be saved by the export file/excel functions.


### 5.2.1 Actuator Setup

“Actuator Setup” contains the actuator settings and allows to view and modify the configuration of actuator according to permission of username.

Data are grouped in TAB (Base Card, 4-20mA Card, bus card, etc). If card is not present in the actuator, the relevant TAB is not shown. Use the F02 (EPI 2) instruction manuals to configure the actuators parameters.

The following example allows to view or change Base card parameters :

- Click “Actuator Setup”, click “Base card”




## 5.2.2 Operation

“**Operation**” is active only if A-Manager works in “**connected**” mode and can be used to send commands to actuator and read status and alarm information.


Confirmation is required to enter in this section. To send commands to actuator is available only according to permission of username. On the PC screen appears the actuator position , torque and temperature and the list of alarms.

Click “On” and then “Send” to enable control by PC via Bluetooth. Click Open/Close/Stop to control the actuator. If actuator is provided with 4-20mA card and positioning function set the percentage of position request and then click Send.



### 5.2.3 Tools

This section permits to import and export configurations from and to files, connection / disconnection from actuator and to change the Bluetooth module name. Data are grouped in two TAB (Import/Export, Utility). Availability of the write operations is according to username permission.



The TAB “**Import/Export**” allows the following :

**Export file:** in connected mode it allows to read from actuator and save the present set of actuator data in a file. Files are exported with extension **\*.f02**. In disconnected mode the data in the A-Manager application memory are saved.

**Export EXCEL:** in connected mode it allows to read from actuator and save the complete (or per section) set of actuator data in an EXCEL file. In disconnected mode the data in the A-Manager application memory are saved.

**Import file:** read the complete (or per section) set of actuator data , previously saved, and then send them or not to actuator. To send and modify data is not allowed in **Observer** username. Files previously exported with A-Manager version less than 4.00 (**\*.set , \*.man**) need the conversion in files compatible with the version 4.0.0 . See par. 7 “A-Manager Conversion Tool”.

Few data cannot be written to actuator. See the list of the above data in par. 8.1 “Username profiles and permissions”, Table 3

The TAB “**Utility**” allows the following commands :


**Connect /Disconnect** to/from actuator (connected or not connected working mode). After the disconnection of A-manager from an actuator, it needs to wait at least 30 sec before re-connecting the same actuator.

**Change Bluetooth module name:** it allows to change the actuator name ( with Bluetooth channel) .

The TAB “**Real Time Logger**” is not available, it is a function used for special test in factory



Below is the screen of the TAB “Utility”.




#### Change Bluetooth module name

The procedure is the following:



- enter the new name and then click Send. If Bluetooth uses the Microsoft driver to update the name it need to exit from A-Manager, reboot the PC or remove and then re-insert the Bluetooth adapter, re-power the actuator and than run again the A-manager. Alternatively use the manual discovery of Bluetooth device to update internal cash memory of PC
- If a WIDCOM driver is used the procedure to update depends on the driver type. Refer to instruction manual of driver to update the Bluetooth name.

## 5.3 Options environment

The Options environment allows the user to modify the application configuration parameters and passwords management. Three sections are available: Modify Config, Password, Object list





- Modify config:** it allows only to change the language , Italian or English. In fact, on F02 actuator only Bluetooth channel is available. Click “Save configuration” and then EXIT from A-Manager and run the program again.
- Password:** it allows to change “observer” and “user” passwords. Press “Confirm” to save changes. Changes are applied with no need to restart the application.
- Object list.** it allows to see the object list number and the description of the object function. Click Export Object list to export in an Excel file. Select folder and name and then click Save



## 5.4 Examples for F02 (EPI 2)



### 5.4.1 To modify the opening torque limit

With A-Manager working in connected mode, click Actuator environment, and Actuator Setup section.. The A-Manager reads the actuator setup parameters from actuator.



Reading data from actuator is done by object. Click TAB “Base Card”, then click “Modify”. The Modify operation is not allowed with username Observer, according to permission profile.


Enter the new opening torque value (87%) and then click Send.



The new value will be sent to actuator and then Modify button disabled. New modify session is available by clicking again “Modify”. Click “Refresh” to check the change has done.


## 5.4.2 To export the actuator data to File

In the Actuator environment, Tools section, Import/Export tab, press “Export file”. The following save file dialog will appear.



Select destination folder and name of file and press Save. A files with extension \*.f02 will be created. The proposed name is a string of characters that includes actuator type, date and time.

Press YES to read the complete set of data from actuator, Press No to save the data present in the current application memory. It is important to understand the difference: data currently in the application memory could or couldn't be the same data of the actuator (especially maintenance data can change very often). So to be sure to export hot actuator data, press “Yes” when asked to read data from actuator.



A message will inform you when the export process is complete.

Now the configuration is saved in the specified files. Later it is possible to import this configuration by pressing the “Import file” button.




Export data is made by object number. If some data is not correct or out of limits or communication is lost, an error message will appears with the Abort, Re-tray, Ignore options. The Object list in the Options environment will help in finding the description of the incorrect data .

### 5.4.3 To export the actuator data to EXCEL file

The function allows saving in an Excel file the complete actuator data.

In the Actuator environment, Tools section, Import/Export tab, press “Export Excel”.

The following file dialog appears. Select destination folder and name of file and press Save. A files with extension \*.xls will be created. The proposed name is a string of characters that includes actuator type, date and time.



Press YES to read the complete set of data from actuator, Press No to save the data present in the current application memory. It is important to understand the difference: data currently in the application memory could or couldn't be the same data of the actuator (especially maintenance data can change very often). So to be sure to export hot actuator data, press “Yes” when asked to read data from actuator.


When conversion is finished the new file will be open.

Export data is made by object number. If some data is not correct or out of limits an error message will appears with the Abort, Re-tray, Ignore options. The Object list in the Options environment will help in finding the description of incorrect data .


	A	B	C	D	E	F	G	H	I	J
1										
2		Actuator: F02 .... Base Card								
3										
4										
5		Base Card								
6	Speed Opening		15							
7	Speed Closing		15							
8	Torque Opening		100							
9	Torque Closing		100							
10	Opening by	Open by Position								
11	Closing by	Close by Position								
12	Size (Nm)	500 Nm								
13	CCW	Off								
14	Led Color Inverted	Off								
15										
16										
17										
18										
19										
20										
21										
22										
23										
24										
25										
26										
27										
28										
29										
30										
31										
32										
33										
34										

## 5.4.4 To import the actuator data from file


In the Actuator environment, Tools section, Import/Export tab, press “Import file”. Only files with \*.f02 extension can be imported. See par. 7, A-Manager Conversion Tool, to import file with different extension. A-manager can work either in “connected” mode or in “not connected” mode. In “connected” mode the imported data can be sent or modified and then sent to actuator. In “not connected” mode the imported data can be modified and then exported in a new file.



Select the file to be imported and then click Open. Now the actuator data are in application memory of A-Manager. Select the group of data to send to actuator and then press OK or alternatively press Cancel if data should not be written to actuator or if A-Manager works in “disconnected” mode. Selected data will be sent to actuator only if enabled by the username profile and will be memorized in the actuator memory.



Import data is made by object number. If some data is not correct or out of limits an error message will appears. With the Abort, Re-tray, Ignore options. The Object list in the Options environment can help in discovering the incorrect data. A report is generated if some object is not supported or out of limits.







## 5.4.5 To set new stroke limits in closure

Disable position request ( OFF) in the optional module (if it is present)



### 5.4.5.1 Closure by torque

In actuator environment, Operation section , click ON the Bluetooth controls and then click Send. Click Open / Close / Stop to move the actuator in intermediate position, about 50%.



Click OFF Bluetooth controls and then click Send. In Actuator environment, Actuator Setup section, TAB base Card, click Modify, Close by torque and New Close limit. Click Send , then Click YES. Actuator moves in close direction and find the new close limit by torque.



In actuator environment, Operation section, see the actuator position.



### 5.4.5.2 Closure by position



Since Closure by Position procedure allows only to reduce the actuator travel it needs to place the actuator in the maximum close position by the Torque Closure procedure (see par. 5.4.5.1) .

Then, in Actuator environment, Operation section , click “On” the Bluetooth controls and then click “Send”. Click Open / Close / Stop to move the actuator in the desired close position. click “Off” the Bluetooth controls and then click “Send”.



In Actuator environment, Actuator Setup section, TAB base Card, click Modify, Close by position and New Close limit. Click Send.

In actuator environment, Operation section, see the actuator position.



## 5.5 Distinguish OLD/NEW models for F02-EPI2

The A MANAGER Interface differently manages some data, depending either on old or on new F02-EPI2 version. For this reason, it is important to distinguish between F02-EPI2 old models and the new ones.

Figure and table below allow distinguishing old and new version of F02-EPI2 (for the NON US MARKET); on the label are underlined the relevant digits of Product Number.



Figure 1 Label for NON US MARKET - Digits X<sub>7</sub>X<sub>8</sub> on product coding chart

Table 1 EPI2/F02 cross reference table for NON US MARKET

ACTUATOR MODEL	OLD	NEW
PRODUCT CODING CHART DIGIT X <sub>7</sub> X <sub>8</sub> 1-PHASE	UV - VU	LV - HV
PRODUCT CODING CHART DIGIT X <sub>7</sub> X <sub>8</sub> 3-PHASE	31, 32, 33	3A, 3B, 3C

Figure and table below allow distinguishing old and new version of F02-EPI2 (for the US MARKET); on the label is underlined the relevant digit of Product Number.




Figure 2 Label for US MARKET – Digit 6 on product coding chart

Table 2 EPI2/F02 cross reference table US MARKET

ACTUATOR MODEL	OLD	NEW
PRODUCT CODING CHART DIGIT 6 1-PHASE	0 - 4	L - H
PRODUCT CODING CHART DIGIT 6 3-PHASE	1, 2, 3	A, B, C

### 5.5.1 A MANAGER Interface differences into new F02-EPI2 version

#### 5.5.1.1 OPENING/CLOSING SPEED (ACTUATOR SETUP section)

New version of EPI2/F02 has only the opening/closing speeds 4, 6 and 8 (see VCIOM-02819).

Opening/Closing speeds read from actuator (Refresh button) are the red ones shows in table below.

When the A MANAGER Interface tries to modify opening/closing speeds (Modify button), actuator logic sets values according to the following table.

Opening/Closing speed sent from A MANAGER Interface	Opening/Closing speed set into new F02-EPI2 version actuator
90 sec	48 sec (4)
70 sec	48 sec (4)
60 sec	48 sec (4)
50 sec	48 sec (4)
40 sec	48 sec (4)
32 sec	28 sec (6)
22 sec	28 sec (6)
15 sec	28 sec (6)
12 sec	15 sec (8)
10 sec	15 sec (8)

### 5.5.1.2 OPENING/CLOSING TORQUE (ACTUATOR SETUP section)

New version of EPI2/F02 has only the opening/closing torque 2, 5 and 9 (see VCIOM-02819).

Opening/Closing torque read from actuator (Refresh button) are the red ones shows in table below.

When the A MANAGER Interface tries to modify opening/closing torque, actuator logic sets values according to the following table:

Opening/Closing torque sent from A MANAGER Interface (% of Nominal Torque)	Opening/Closing torque set into new F02-EPI2 version actuator
40%	50% (2)
47%	50% (2)
53%	50% (2)
60%	50% (2)
67%	75% (5)
73%	75% (5)
80%	75% (5)
87%	100% (9)
93%	100% (9)
100%	100% (9)

### 5.5.1.3 TORQUE (OPERATION section)

Into OPERATION section, Data TORQUE has different meaning in function of old and new F02-EPI2 models. In particular, in old F02-EPI2 models it is the current Torque value; in new models it is the set Torque value.



## 6 A-Manager for MCU 2000 v4

The MCU 2000v4 uses the same logic board of ICON/F01/EFS 2000v4. Consequently also A-Manager features and instructions are the same

Refer to par. 4 , A-Manager for ICON/F01/EFS 2000, and to MCU instruction manual for detailed description of features and examples.

### 6.1 User Interface

The user interface is organized in environments and sections. Environments are grouped in the horizontal navigation bar on the top of the screen. Each environment contains sections that are listed in the vertical navigation bar on the left. At present two environments are available : Actuator and Options. The following sections are available in each environment:

Environment	Actuator	Environment	Options
<b>S</b>	Actuator Setup	<b>S</b>	Modify Config
<b>E</b>	Name Plate	<b>E</b>	Password
<b>C</b>	Valve data	<b>C</b>	Object List
<b>T</b>	Maintenance	<b>T</b>	
<b>I</b>	Restricted	<b>I</b>	
<b>O</b>	Operations	<b>O</b>	
<b>N</b>	Tools	<b>N</b>	

Actuator Setup: it contains actuator configuration settings

Name Plate: it contains actuator name plate data

Valve Data: it contains data about the valve onto which the actuator is mounted

Maintenance: it contains maintenance and diagnostics information;

Restricted: it contains actuator advanced settings.

Operations: it is used to remotely send commands to actuator and to read status and alarm information;

Tools: it is used to read and write Card Reports. This section also permits to import and export configurations from and to files, reading and updating actuator firmware, and to send various utility commands to actuator.

Modify config: it is used to change the A-Manager settings. The following data can be modified:

- Communication data: Channel, COM n°, Speed
- Language Italian or English

Password: it allows to change “observer” and “user” passwords



Object list. It allows to see the object list number and the description of the object function

If username is not enabled to access to a particular section or environment, the relative button will be disabled.

Sections are organized in TAB's. Each tab contains a subset of information that can be read from and written to the actuator. The data of TAB's are grouped according to organization in the actuator local menu.

Once Environment and Section are selected, click TAB of data to be viewed.





## 6.2 Actuator environment

The Actuator Environment contains information about configuration settings and actuator management. Click Actuator to select the environment.


Click the Section to view. If the A-Manger works in “connected” mode the data of the section are read from actuator. Click the TAB to view the data on the PC screen. Use button **Refresh** to read again all data of selected TAB. Use button **Modify** to activate the “modify data” option. Modify the data in the selected TAB and then click **Send** to send all data of **selected TAB** to actuator or click **Undo** if data should not be changed. Only data of the selected TAB will be sent to actuator. Option **Modify** and **Send** are enabled according to username profile. In Observer username the options **Modify** and **Send** are disabled. In “disconnected” mode use **Modify** and **Send** can be used to change values of parameter of previously imported file. The modified data can only be saved by the export file/excel functions.

### 6.2.1 Actuator Setup

“Actuator Setup” contains the actuator settings and it allows to view and modify the configuration of actuator according to permission of username.

Data are grouped in TAB (Fail Safe & Interlock, Positioner, Miscellaneous , etc), according to the same organization in the actuator local menu. Use the MCU 2000 v4 instruction manuals to configure the actuators parameters. The following example allows to view or change the “Positioner & out 4-20mA parameters :

- Click “Actuator Setup”, click “Positioner & Out 420mA”



## 6.2.2 Name Plate

“Name Plate” contains the actuator name plate and it is possible to view and modify the actuator data according to permission of username. Data are grouped in TAB (Actuator data, Actuator Speed, Power Supply , etc), according to the same organization in the actuator local menu. Use the MCU 2000 v4 instruction manuals to see name plate parameters description.

The following example allows to view or change the TAB “Actuator Data” :

- Click “Name Plate”, click “Actuator Data”

AMANAGER - Name Plate

Actuator Management | **Actuator** | Statistics | Options

Actuator Setup | **Name Plate** | Valve Data | Maintenance | Restricted | Operations | Tools

Actuator Data | Actuator Speed | Torque / Thrust | Power Supply | Motor Data | Test date & Revision

Actuator Data

Serial Number	031234E02001
Actuator Type	ALGAS
Wiring diagram	SEARA003
Enclosure	Ex-d-IIC
Certificate	ATEX
Lubricant	SHELL_TIVELA

Ver. 4.0.2 MCU

Refresh | Modify | Send

Username | Manufacturer (Logout) | Actuator S/N 031234E02001 | Working Mode Connected at 115200 bps (RS232)

### 6.2.3 Valve Data

“Valve data” contains the data relevant to the valve and it is possible to view and modify the above data according to permission of username. Data are grouped in one only TAB (Tag, Serial Number, etc), according to the same organization in the actuator local menu. Use the MCU 2000 v4 instruction manuals to see valve parameters description. Click “Valve Data” on the Main Menu to view the valve data values.

The screenshot shows the 'AMANAGER - Valve Data' window. The interface includes a sidebar on the left with the following menu items: Actuator Setup, Name Plate, Valve Data (highlighted), Maintenance, Restricted, Operations, and Tools. The main content area features a background image of a valve actuator and several data entry fields:

- Tag: #5001
- Serial Number: q234f
- Valve Manufacturer: VANESSA
- Break to open torque: 200Kgm
- Max stem thrust: 50kg
- Valve coupling type: ISO...

At the bottom of the window, there is a status bar containing the following information:


- Ver. 4.0.2 MCU
- Buttons: Refresh, Modify, Send
- Username: Manufacturer (Logout)
- Actuator S/N: 031234E02001
- Working Mode: Connected at 115200 bps (RS232)



## 6.2.4 Maintenance

“Maintenance” contains the data relevant to the actuator maintenance and it is possible to view and modify the above data according to permission of username. Data are grouped in TAB (Data Logger, Alarm Log, etc), according to the same organization in the actuator local menu. Use the MCU 2000 v4 instruction manuals to see data description. The following example allows to view or change the “Data Logger” :

- Click “Maintenance” and then “Data Logger”



## 6.2.5 Restricted

“Restricted” contains advanced actuator settings. It is possible to view data, but to modify them is allowed only with Service or Manufacturer username. Data are grouped in TAB (One, Two, etc), according to the same organization in the actuator local menu. The following example allows to view or change the TAB “One” :

- Click “Restricted”, click “One”

The screenshot displays the 'AMANAGER - Restricted' software window. The interface includes a top navigation bar with tabs for 'Actuator Management', 'Actuator' (selected), 'Statistics', and 'Options'. On the left, a sidebar menu lists various settings: 'Actuator Setup', 'Name Plate', 'Valve Data', 'Maintenance', 'Restricted' (highlighted), 'Operations', and 'Tools'. The main area shows the 'One' tab settings, which include:

- Reversal Delay:** 1 sec
- Torque Stop Zone:** 5 %
- 4-20 mA Config:**
  - I=4mA: 738
  - I=20mA: 3642
  - O=4mA: 767
  - O=20mA: 3840
- 4-20mA Card:** ☒ Absent, ☐ Present
- Bluetooth Module:** ☒ Disable, ☐ Enable
- Irda:** ☒ Disable, ☐ Enable
- Back Light:** ☒ Auto, ☐ On
- Additional Variables:** ☒ Mask, ☐ View
- Heater Ref. (°C):**
  - Base: -40
  - Display: -40
  - Term. Board: -40
- Interlock Mode:** ☒ Standard, ☐ Advanced
- Hardware configuration:** Base
- Software type:** MCU

A warning message at the bottom of the settings area states: '\* Changing this setting will cause the disconnection from the actuator'. At the bottom of the window, there are buttons for 'Refresh', 'Modify', and 'Send'. The status bar at the very bottom shows 'Username: Manufacturer (Logout)', 'Actuator S/N: 031234E02001', and 'Working Mode: Connected at 115200 bps (RS232)'.

## 6.2.6 Operation

“Operation” is active only if A-Manager works in “connected” mode and can be used to send commands to actuator and read status and alarm information.

Confirmation is required to enter in this section. To send commands to actuator is available only according to permission of username, if the selector is in LOCAL and if the appropriate actuator setting was done. On the PC screen are the same information available in the actuator local displays and also the value of the main important variables (SOV trim lifting, temperature, Sp, etc.). Also **Purge** command is available


The button Output Contacts allows to see the status of output relays, Monitor relay and Auxiliary relays Asi. The button “Alarm/Warning” allows to see the list of alarms and warnings. The line of present Alarms and Warnings are red. The button Bus Information allows to see various data relevant to Bus Interface (if it is present). The button Other Info allows to see various data relevant internal counters, A to D converter, etc. The button Reset Alarm/ Warning allows to send a “reset Alarm and Warning” command to actuator.




AMANAGER - Alarms and warnings									
Alarms									
Configuration	Status	Mid Travel Off	Status	HWS: Varing Configuration	Status	SOV2 sensor	Status		
Internal Temperature	Off	HWS: Local Push-Button and Selector	Off	HWS2: Varing Configuration of Bus Card Type	Off	PV transmitter	Off		
Jammed in CL	Off	Request Signal	Off	HWS3: No Communication Between Base and Bus	Off				
Jammed in OF	Off	HWS2: Varing Configuration 4-20mA	Off	HWS3: No Comm. of Power MCU	Off				
Position Sensor	Off	HWS2: Stroke not Responding	Off	HWS3: No Comm. of HPU Terminal Board	Off				
Main Supply	Off	HWS4: Terminal Board Configuration	Off	Pump alarm	Off				
Mid Travel CL	Off	HWS5: No Comm. Terminal Board	Off	SOV3 sensor	Off				
Warnings									
Max. Contactor Cycles	Status	Pump 2 Pres. Sw.	Status	Low H2	Status	Pump 2 Low Pressure	Status		
Maintenance Request	Off	Leakage	Off	Clogged filter	Off	Pump 2 Oil Hi Temp.	Off		
Varing Stroke Limits	Off	Error PV > 4%	Off	Hi Temperature	Off	Pump 2 Met. Supply	Off		
Bus Fail	Off	Pump 1 Sensor	Off	Pump 1 Low Pressure	Off	Pump 2 Low Level	Off		
Pump 1 Met. Therm.	Off	Pump 2 Sensor	Off	Pump 1 Oil Hi Temp.	Off				
Pump 1 Pres. Sw.	Off	Low PV	Off	Pump 1 Met. Supply	Off				
Pump 2 Met. Therm.	Off	High PV	Off	Pump 1 Low Level	Off				

Alarm / warning list


The figures below show the PURGE command.



Move local selector to Local



Set the opening or closing duty cycle and then click Send to start opening or closing



Click Off to stop movement

## 6.2.7 Tools

“Tools” is used to read and write Card Reports. This section also permits to import and export configurations from and to files, reading and updating actuator firmware, and to send various utility commands to actuator. Data are grouped in TAB , Card report, Import/Export, Firmware/Language, Utility, etc). Availability of the various write operations is according to username profile and permission.

The TAB “Card report” allows to see information relevant to electronic cards present in the actuator.

The TAB “Import/Export” allows the following :

**Export file:** in connected mode it allows to read from actuator and save the present set of actuator data in a file. Files are exported with extension \*.mcu. In disconnected mode the data in the A-Manager application memory are saved.

**Export EXCEL:** in connected mode it allows to read from actuator and save the complete (or per section) set of actuator data in an EXCEL file. In disconnected mode only the data in the A-Manager application memory can be exported.

**Import file:** read the complete (or per section) set of actuator data , previously saved, and then send them or not to actuator. See “Examples for ICON/F01/EF5 2000v4”, “To import the actuator data from file”, par. 4.4.4, to see description of “Import file” feature and examples.

Few data can be written to actuator only in TAB by TAB mode (see par. 4.4.4.2, “To write new data to actuator in TAB by TAB mode”), and most of maintenance data cannot be written to actuator. See the list of the above data in par. 8.3 “Username profiles and permissions”, Table 4 and Table 5


The TAB “**Firmware/ Language**” allows to download a new firmware and language file to actuator.

The TAB “Utility” allows the following commands :

- Connect /Disconnect to/from actuator (connected or not connected working mode). In Bluetooth mode, after the disconnection of A-manager from an actuator, it needs to wait at least 30 sec before re-connecting the same actuator.
- Change Baud Rate , see also par. 3.3 Setup
- Wink: in connected mode the command causes the 3 LED’s of actuator to blink

- Set Icon Selector: in connected mode the command allows to virtually change the position of actuator local selector from Local, Off, and Clear. Press Local to move the virtual selector to Local, press Off to move the virtual selector to Off . The control will be restored to real actuator local selector by sending Clear or by closing the communication channel between actuator and PC or by re-powering the actuator.
- Change Bluetooth module name: it allows to change the actuator name ( with Bluetooth channel) from actuator serial number to valve tag.

Below is the screen of the TAB “Utility”.



#### Change Bluetooth module name


The procedure is the following:

- Click Modify, select Serial Number or Valve Tag and then click Send. If Bluetooth uses the Microsoft driver to update the name it need to exit from A-Manager, reboot the PC or remove and then re-insert the Bluetooth adapter, re-power the actuator and than run again the A-manager.
- If a WIDCOM driver is used the procedure to update depends on the driver type. Refer to instruction manual of driver to update the Bluetooth name.



## 6.3 Options environment

The Options environment allows the user to modify the application configuration parameters and passwords management. Three sections are available: Modify Config., Password, Object list





Modify config: used to change the A-Manager settings. The following data can be modified:

- Communication data: RS-232, Bluetooth™
- COM Port number: the number of the COM port to open
- Connection speed: 9.600bps or 115.200bps
- Language: Italian or English

Click Save configuration and then EXIT from A-Manager and run the program again.

Password: it allows to change “observer” and “user” passwords. Press “Confirm” to save changes. Changes are applied with no need to restart the application.

Object list. it allows to see the object list number and the description of the object function. Click Export Object list to export in an Excel file. Select folder and name and then click save





## 7 A-Manager conversion tool

A-Manager version 4.x.x can import only files with extension \*.icon, \*.f02, \*.mcu . A-Manager Conversion Tool allows to import files with extension \*.set and \*.man , previously exported by A\_Manager version less then 4.0.0 Also files saved with extension \*.i4k, by the program tool prjICON4K.exe can be converted in \*.icon files. Here below are instruction to install the A-Manager Conversion Tool and to convert old files in the format compatible with A-Manager version 4.x.x


Important:



“A MANAGER” Conversion Tool consists of one only file:  
ConversionTools\_x.x.x.msi

### 7.1 Installation process


To start the installation process, double-click on ConversionTools\_x.x.x.msi. A simple wizard will guide you through the installation process:



Click Next.

Agree to End User License Agreement

Select installation folder and then click Next




Click “Next” to begin program installation. Click Close when installation is completed

A link (icon with BIFFI logo named AManager) to the executable file (AManager Conversion Tool.exe) will be created on your desktop and a new program folder, named “Biffi Italy”, will be added to your Start Menu\Program folder. Double-click one of the links to the executable file or the executable file itself (located in : \destination\_folder\bin\ ) to run the program.


## 7.2 Start the Program

“A Manager Conversion Tool” for PC starts with the following screen.

### 7.2.1 Conversion of file \*.set




Click the button “...” in the line of Source.set file. Select source folder and source file \*.set. Click Open




Click the button “...” in the line of Destination file. Select destination folder and destination file .  
Click Save, then click Convert to start conversion. At the end of conversion, the message “conversion completed” appears and the file with extension .icon, or .f02, is available in the destination folder.


Now by A-Manager for PC working in “**disconnected**” mode open the file and use import function to check that conversion of file is correct.



## 7.2.2 Conversion of file \*.i4k




Click the button “...” in the line of Source.i4k file. Select source folder and source file \*.set. Click Open



Click Save, then click Convert to start conversion. At the end of conversion , the message “conversion completed” appears and the file with extension \*.icon is available in the destination folder.

Now by A-Manager for PC working in “disconnected” mode open the file and use import function to check that conversion of file is correct.



## 8 Username profiles and permissions

Each user profile has defined permissions and restrictions associated to. Here are listed the permissions associated to the profiles “Observer”, “User” and “Service”.

### 8.1 Permissions for ICON/F01/EFS 2000v4

“**Observer**” username, is the user with more restrictions; the only actions he can perform are: reading data from actuator, exporting files, importing files in the PC local memory . In particular :

- Actuator Setup :
  - Read : allowed;
  - Write: not allowed;
  - Modify OP/CL limits commands (Stroke limits and Torque setup TAB: not allowed)
  - Modify/Send TAB “stroke limits data”: not allowed
  - Default #1,2 commands (TAB Miscellaneous ) : not allowed
- Name Plate :
  - Read : allowed;
  - Write : not allowed;
- Valve Data :
  - Read : allowed;
  - Write : not allowed;
- Maintenance :
  - Read : allowed;
  - Write : not allowed;
  - “clear recent log” command : not allowed;
  - “set data logger” : not allowed
  - “set reference Torque/PST/EFS” commands : not allowed;
  - “PST command” : not allowed
- Restricted :
  - Read : not allowed;
  - Write : not allowed;
- Operations :
  - Operation command (Open, Close, Stop) : not allowed;
  - “Reset Alarm/Warnings” commands: not allowed;
- Tools :
  - Read : allowed;
  - Write : not allowed;
  - Export : allowed;
  - Import : allowed only in local memory. Not allowed to write configuration to the actuator;
  - Firmware management : not allowed;
  - Utilities commands: allowed.

“**User**” username, can read and write data from/to the actuator and send commands (Open, Close, Stop). In particular (the differences with “Observer” profile are marked in bold):

- Actuator Setup :
  - Read : allowed;
  - Write: **allowed**;
  - Modify OP/CL limits commands (Stroke limits and Torque setup TAB: **allowed**)
  - Modify/Send TAB “stroke limits data”: not allowed
  - Default #1,2 commands (TAB Miscellaneous ) : **allowed**
- Name Plate :
  - Read : allowed;
  - Write : not allowed;
- Valve Data :

- Read : allowed;
  - Write : **allowed**;
- Maintenance :
  - Read : allowed;
  - Write : **allowed**;
  - “clear recent log” command : **allowed**;
  - “set data logger” : **allowed** (even if the local selector is in Local or Remote);
  - “set reference Torque/PST/EFS” commands : **allowed**;
  - “PST command” : **allowed**;
- Restricted : **allowed**
  - Read : **allowed**;
  - Write : not allowed;
- Operations :
  - Operation command (Open, Close, Stop) : **allowed**;
  - “Reset Alarm/Warnings” commands: **allowed** (even if the local selector is in Local or Remote);
- Tools :
  - Read : allowed;
  - Write : not allowed;
  - Export : **allowed**;
  - Import : **allowed**; (not allowed writing Name Plate and Restricted data to actuator)
  - Firmware management : not allowed;
  - Utilities commands: **allowed**.

“Service” username, can read and write data from/to the actuator and send commands (Open, Close, Stop). Service username is allowed to modify Restricted section, Name Plate section and TAB “stroke limits data”. It is not allowed to modify TAB “Card Report”.

“Manufacturer” username has no restrictions

Few data can be written to actuator only in TAB by TAB mode, and most of maintenance data cannot be written to actuator. Below is the list of data writable in TAB by TAB mode (table 1) and not writable (Table 2).

**Table 1 :** Objects writable to actuator in TAB by TAB mode and according to permission profile

Section	TAB
Actuator Setup	Stroke Limits Data
Restricted	Two, Bluetooth module
Restricted	Two, IrDA
Restricted	One, Voltage span
Restricted	One, Current sensor
Restricted	One, 4-20mA Config

**Table 2:** Objects not writable to actuator

Section	TAB
Name Plate	Test date & Revision, Revision Software
Actuator setup	FDI control
Operation	All data
Maintenance	All data except TAB “Maintenance Dates” and Data Logger Setup?

## 8.2 Permissions for F02 (EPI 2)

“**Observer**” username, is the user with more restrictions; the only actions he can perform are: reading data from actuator, exporting files, importing files in the PC local memory. In particular:

- Actuator Setup :
  - Read : allowed;
  - Write: not allowed;
- Operations :
  - Operation command (Open, Close, Stop) : not allowed;
- Tools :
  - Export : allowed;
  - Import : allowed only in local memory. Not allowed to write configuration to the actuator;
  - Utilities commands:
    - Connect/Disconnect: allowed.
    - Change Bluetooth name: not allowed

“**User**” username, can read and write data from/to the actuator and send commands (Open, Close, Stop). In particular (the differences with “Observer” profile are marked in bold):

- Actuator Setup :
  - Read : allowed;
  - Write: **allowed**;
- Operations :
  - Operation command (Open, Close, Stop) : **allowed**;
- Tools :
  - Export : allowed;
  - Import : **allowed**;
  - Utilities commands:
    - Connect/Disconnect: allowed.
    - Change Bluetooth name: **allowed**

“**Service**” and “**Manufacturer**” username have the same permissions of “**User**” username.

Few data cannot be written to actuator since their values are set in the firmware. The following tables shows the list of data not writable.

**Table 3:** Objects not writable to actuator

TAB	Function
Optional card	FW version of optional card
Optional card	HW revision of optional card
Base card	Operation, Status of base card
Optional card	Bus parameter
Optional card	DeviceNet serial number



## 8.3 Permissions for MCU 2000v4

“**Observer**” username, is the user with more restrictions; the only actions he can perform are: reading data from actuator, exporting files, importing files in the PC local memory. In particular:

- Actuator Setup :
  - Read : allowed;
  - Write: not allowed;
  - Modify OP/CL limits commands (Stroke limits TAB) : not allowed
  - Modify/Send TAB “stroke limits data”: not allowed
  - Default #1,2 commands (TAB Miscellaneous ) : not allowed
  - SOV Calib : not allowed
  - Stroke limit autocalibration command : not allowed
- Name Plate :
  - Read : allowed;
  - Write : not allowed;
- Valve Data :
  - Read : allowed;
  - Write : not allowed;
- Maintenance :
  - Read : allowed;
  - Write : not allowed;
  - “set data logger” : not allowed
  - “clear recent log” command : not allowed;
- Restricted :
  - Read : not allowed;
  - Write : not allowed;
- Operations :
  - Operation command (Open, Close, Stop) : not allowed;
  - “Reset Alarm/Warnings” commands: not allowed;
  - “Purge” command : not allowed
- Tools :
  - Read : allowed;
  - Write : not allowed;
  - Export : allowed;
  - Import : allowed only in local memory. Not allowed to write configuration to the actuator;
  - Firmware management : not allowed;
  - Utilities commands: allowed.

“**User**” username, can read and write data from/to the actuator and send commands (Open, Close, Stop). In particular (the differences with “Observer” profile are marked in bold):

- Actuator Setup :
  - Read : allowed;
  - Write: not allowed;
  - Modify OP/CL limits commands (Stroke limits TAB) : **allowed**
  - Modify/Send TAB “stroke limits data”: not allowed
  - Default #1,2 commands (TAB Miscellaneous ) : **allowed**
  - SOV Calib : **allowed**
  - Stroke limit autocalibration command : **allowed**
- Name Plate :
  - Read : allowed;
  - Write : not allowed;
- Valve Data :
  - Read : allowed;
  - Write : **allowed**;
- Maintenance :
  - Read : allowed;

- Write : **allowed**;
- “set data logger” : **allowed** (even if the local selector is in Local or Remote);
- “clear recent log” command : **allowed**;
- Restricted :
  - Read : **allowed**;
  - Write : not allowed;
- Operations :
  - Operation command (Open, Close, Stop) : **allowed**;
  - “Reset Alarm/Warnings” commands: **allowed** (even if the local selector is in Local or Remote);
  - “Purge” command : **allowed**
- Tools :
  - Read : **allowed**;
  - Write : not allowed;
  - Export : **allowed**;
  - Import : **allowed**; (not allowed writing Name Plate and Restricted data to actuator)
  - Firmware management : not allowed;
  - Utilities commands: **allowed**.

“**Service**” username, can read and write data from/to the actuator and send commands (Open, Close, Stop). Service username is allowed to modify Restricted section, Name Plate section and TAB “stroke limits data”. It is not allowed to modify TAB “Card Report”.

“**Manufacturer**” username has no restrictions.

Few data can be written to actuator only in TAB by TAB mode, and most of maintenance data cannot be written to actuator. Below is the list of data writable in TAB by TAB mode (table 4) and not writable (Table 5).

Table 4 : Objects writable to actuator in TAB by TAB mode and according to permission profile

Environment	Section	TAB
Actuator	Actuator Setup	Stroke Limits Data
Actuator	Restricted	Two, Bluetooth module
Actuator	Restricted	Two, IrDA
Actuator	Restricted	Three, PV Analog Input 20mA
Actuator	Restricted	Three, PV Analog Input 20mA
Actuator	Restricted	One, 4-20mA Config


Table 5 : Objects not writable to actuator

Environment	Section	TAB
Actuator	Name Plate	Test date & Revision, Revision Software
Actuator	Actuator setup	FDI control
Actuator	Operation	All data
Actuator	Maintenance	All data except TAB “Dates”


## 9 Exception messages

Here below are described the most common exception messages generated by the A-Manager:


Use the Object List and relevant Object description, available in Options environment, par. 4.3, 5.3 and 6.3 to find and correct the wrong data.




Click ignore if object is not supported by the actuator firmware.  
Click Re-tray to read again the object  
Click Abort to stop the procedure



Click Re-tray to read again the object or  
click Abort to stop the procedure




Find the object in the Object list.  
See the object description and then move  
in the Section and TAB containing the  
Object.  
Enter correct values by the commands  
Modify and Send



Object cannot be written :

- not supported by the firmware revision of actuator or
- username profile does not allow to write it





BIFFI ITALIA s.r.l.  
Loc. Caselle S. Pietro  
29017 Fiorenzuola d'Arda -Piacenza - ITALY -  
Tel. (0523) 944411 - Fax (0523) 941885  
E\_mail: [biffi\\_italia@biffi.it](mailto:biffi_italia@biffi.it)